

SPRAY CLEANER

Intensive cleaner effective on all kind of stains



Description

SPRAY CLEANER is a spray cleaner suitable for the removal of all the kind of deep stains. SPRAY CLEANER clean acts with strong efficacy, solubilizing even the tough dirt, where the regular detergent is not effective. It does not leave halos and it does not discolor the material.

Characteristics

Application	spray
Application temperature	+5°C ÷ +30°C
Packaging	200 ml
Storage stability	1 year ⁽¹⁾

1 in original sealed containers at temperatures between +10°C and +25°C

How to use

Shake well SPRAY CLEANER before the use.

Spray SPRAY CLEANER directly on the spots that have to be removed, keeping a 25 cm distance. Let the product acts for at least 2-3 minutes than brush and rinse with water. In case of tough dirt re-apply SPRAY CLEANER following the same procedure.

Warnings

Keep out of children's reach. If medical advice needed, have product container or label at hand.

Label elements

· Extremely flammable aerosol. · Pressurized container: may burst if heated. · May be fatal if swallowed and enters airways.

· Repeated exposure may cause skin dryness or cracking.

· Keep out of reach of children. · Keep away from heat / sparks / open flames / hot surfaces. No smoking. · Do not spray on an open flame or other ignition source. · Pressurized container: do not pierce or burn, even after use. · DO NOT induce vomiting. · Protect from sunlight. Do no expose to temperatures exceeding 50°C / 122°F. · Dispose your waste in dedicated collection points. · Use only outdoors or in a well-ventilated area. · If medical advice is needed, have product container or label at hand. · IF SWALLOWED: Immediately call a POISON CENTER or doctor / physician. · Store locked up.

Contents: Hydrocarbons, C11-C14, isoalkanes, cyclics, <2% aromatics; ETHYLBENZENE;

